



EXT-KA-SE100

Setting up WiFi network through integrated display

Setting up WIFI network through integrated display on EXT-KA-SE100:

1. Access WIFI settings: On EXT-KA-SE100 display, navigate to the "Settings" menu and select "WIFI".
2. Choose Wi-Fi Network: Select the SSID of the WIFI network you want to connect to and enter the password for the chosen WIFI network.

You may manually enter the IP address, Subnet Mask, and Gateway information for manual connection.

EXT-KA-SE100 supports 2.4GHz WIFI, 802.11b/g/n, 64/128 WEP, WPA-PSK, WPA2-PSK, WPA, WPA2.



Internal PKI is not supported.

3. Ensure the "Enabled" button is turned on in green colour. WIFI Configuration is completed.

Setting up Cloud account

Setting up Cloud account:

1. Create Cloud Account on Belimo Indoor Air Quality (IAQ) Portal
 - a. Go to <https://belimo.kaiterra.com/login>
 - b. Click "Sign up here" at the bottom of the page.
 - c. Fill in your email address and create a strong password.
 - d. Confirm password.
 - e. Click "Register."
2. Activate Cloud Account:
 - a. Check your email inbox for an account activation link.
 - b. Click the link to activate your account.



Setting up Cloud account

Adding sensor to Cloud account

1. Log In to Cloud Account:
 - a. Return to <https://belimo.kaiterra.com/login>.
 - b. Enter your email address and password.
 - c. Click "Login."
2. Add EXT-KA-SE100 to Cloud account:
 - a. Click "Add device" in the top right corner of the page.
 - b. Device Name: Create a name for your sensor.
 - c. Device UDID: Navigate to "Settings" on EXT-KA-SE100 integrated screen, then "Device Details." The UDID is listed under "Unique ID."
 - d. Click "Add Device." The cloud setup is completed.

