

Rotary actuator for butterfly valves

- Torque motor 160 Nm
- Nominal voltage AC 24...240 V / DC 24...125 V
- Control modulating, communicative, hybrid
- With 2 integrated auxiliary switches
- Conversion of sensor signals
- Communication via BACnet MS/TP, Modbus RTU, Belimo-MP-Bus or conventional control



ASURAE BACnet™

Modbus

MP BUS

NFC

Picture may differ from product

## Technical data

### Electrical data

Nominal voltage	AC 24...240 V / DC 24...125 V
Nominal voltage frequency	50/60 Hz
Nominal voltage range	AC 19.2...264 V / DC 19.2...137.5 V
Power consumption in operation	20 W
Power consumption in rest position	6 W
Power consumption for wire sizing	with 24 V 20 VA / with 240 V 52 VA
Auxiliary switch	2x SPDT, 1x 10° / 1x 0...90° (default setting 85°)
Connection protective earth	earth terminal
Connection supply	Terminals 2.5 mm <sup>2</sup>
Connection control	Terminals 1.5 mm <sup>2</sup>
Connection auxiliary switch	Terminals 2.5 mm <sup>2</sup>
Parallel operation	Yes (note the performance data)

### Data bus communication

Communicative control	BACnet MS/TP Modbus RTU MP-Bus
Number of nodes	BACnet / Modbus see interface description MP-Bus max. 8 (16)

### Functional data

Torque motor	160 Nm (configured for D6250W/WL)
Operating range Y	2...10 V
Input impedance	100 kΩ
Operating range Y variable	0.5...10 V 4...20 mA
Position feedback U	2...10 V
Position feedback U note	Max. 0.5 mA
Position feedback U variable	0.5...10 V
Position accuracy	±5%
Manual override	hand crank
Running time motor	35 s / 90°
Running time motor variable	30...120 s
Sound power level, motor	68 dB(A)
Position indication	Mechanical, integrated

### Safety data

Protection class IEC/EN	I, protective earth (PE)
Protection class UL	I, protective earth (PE)
Degree of protection IEC/EN	IP66/67
Degree of protection NEMA/UL	NEMA 4X
Housing	UL Enclosure Type 4X
EMC	CE according to 2014/30/EU

## Technical data

<b>Safety data</b>	Low voltage directive	CE according to 2014/35/EU
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14
	UL Approval	cULus according to UL60730-1A, UL60730-2-14 and CAN/CSA E60730-1
		The UL marking on the actuator depends on the production site, the device is UL-compliant in any case
	Type of action	Type 1
	Rated impulse voltage supply	4 kV
	Rated impulse voltage control	0.8 kV
	Rated impulse voltage auxiliary switch	2.5 kV
	Pollution degree	3
	Ambient humidity	Max. 100% RH
	Ambient temperature	-30...50°C [-22...122°F]
	Storage temperature	-40...80°C [-40...176°F]
	Servicing	maintenance-free
<b>Weight</b>	Weight	5.8 kg

## Safety notes



- This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- Caution: Mains voltage!
- The device has a protective earthing. Incorrect connection of the protective earth can lead to hazards due to electrical shock.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.
- Apart from the wiring compartment, the device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- The device is not designed for applications where chemical influences (gases, fluids) are present or for utilisation in corrosive environments in general.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.
- The two switches integrated in the actuator are to be operated either on mains voltage or on safety extra-low voltage. The combination mains voltage/safety extra-low voltage is not permitted.
- In case of maintenance work on the hydronic system, the correct valve position must be set via the control signal. Additionally, the actuator has to be disconnected from the power supply. The hand crank and manual override must not be used as a safety measure to maintain the set valve position.

## Product features

<b>Fields of application</b>	The actuator is particularly suitable for utilisation in outdoor applications and is protected against the following weather conditions: - UV radiation - Dirt / Dust - Rain / Snow - Air humidity
<b>Converter for sensors</b>	Connection option for two sensors (passive, active or switching contacts). In this way, the analogue sensor signal can be easily digitised and transferred to the bus systems BACnet or Modbus.
<b>Internal heating</b>	An internal heater prevents condensation buildup. Thanks to the integrated temperature and humidity sensor, the built-in heater automatically switches on/off.

## Product features

<b>Configurable device</b>	The factory settings cover the most common applications. Parameters can be modified using Belimo Assistant 2, either wirelessly via Near Field Communication (NFC), or via a wired connection.
<b>Combination analogue - communicative (hybrid mode)</b>	With conventional control by means of an analogue control signal, BACnet or Modbus can be used for the communicative position feedback
<b>Simple direct mounting</b>	Simple direct mounting on the butterfly valve. The mounting orientation in relation to the butterfly valve can be selected in 90° (angle) increments.
<b>Manual override</b>	The valve can be manually operated using a hand crank. Unlocking is carried out manually by removing the hand crank.
<b>High functional reliability</b>	The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.
<b>Flexible signalling</b>	The actuator has one auxiliary switch with a fixed setting (10°) and one adjustable auxiliary switch (0...90°).

## Accessories

Tools	Description	Type
	Service tool for wired and wireless setup, on-site operation and troubleshooting.	Belimo Assistant 2
	Belimo Assistant Link Bluetooth and USB to NFC and MP-Bus converter for configurable and communicative devices	LINK.10
	Connecting cable 5 m, A: RJ11 6/4 LINK.10, B: 6-pin for connection to service socket	ZK1-GEN
	Connecting cable 5 m, A: RJ11 6/4 LINK.10, B: free wire end for connection to MP/PP terminal	ZK2-GEN
Electrical accessories	Description	Type
	Signal converter voltage/current 100 kΩ 4...20 mA, Supply AC/DC 24 V	Z-UIC
Mechanical accessories	Description	Type
	Position indicator and tappet shaft, F07, square 45° offset, SW 17, DN 125...300	ZPR01
	Tappet shaft, F07, square 45° offset, SW 17	ZPR02
	Position indicator and tappet shaft, F05, square 45° offset, SW 14, DN 80...100	ZPR03
	Hand crank for PR/PM actuator	ZPR20
Sensors	Description	Type
	Duct/Immersion sensor Temperature 50 mm x 6 mm Pt1000	01DT-1BH
	Duct/Immersion sensor Temperature 50 mm x 6 mm Ni1000	01DT-1CH
	Duct/Immersion sensor Temperature 100 mm x 6 mm Pt1000	01DT-1BL
	Duct/Immersion sensor Temperature 100 mm x 6 mm Ni1000	01DT-1CL
	Duct/Immersion sensor Temperature 150 mm x 6 mm Pt1000	01DT-1BN
	Duct/Immersion sensor Temperature 150 mm x 6 mm Ni1000	01DT-1CN
	Duct/Immersion sensor Temperature 200 mm x 6 mm Pt1000	01DT-1BP
	Duct/Immersion sensor Temperature 200 mm x 6 mm Ni1000	01DT-1CP
	Duct/Immersion sensor Temperature 300 mm x 6 mm Pt1000	01DT-1BR
	Duct/Immersion sensor Temperature 300 mm x 6 mm Ni1000	01DT-1CR
	Duct/Immersion sensor Temperature 450 mm x 6 mm Pt1000	01DT-1BT
	Duct/Immersion sensor Temperature 450 mm x 6 mm Ni1000	01DT-1CT

## Electrical installation





## Caution: Mains voltage!

Parallel connection of other actuators possible. Observe the performance data.

The wiring of the line for BACnet MS/TP / Modbus RTU is to be carried out in accordance with applicable RS-485 regulations.


## Electrical installation

AC 24...240 V / DC 24...125 V




Power supply must not be connected to the signal terminals!

## Modulating control





## Parallel circuit 2...10 V




Setpoint 2...10 V

**Electrical installation**

Parallel circuit 4...20 mA

**Auxiliary switch****Further electrical installations****MP-Bus**

MP-Bus Network topology





There are no restrictions for the network topology (star, ring, tree or mixed forms are permitted). Supply and communication in one and the same 3-wire cable

- no shielding or twisting necessary
- no terminating resistors required

**Functions with specific parameters (configuration necessary)**


Control open/close




## Further electrical installations

## Functions with specific parameters (configuration necessary)


## Control 3-point



## Control 4...20 mA



## Positioner SG..




## Note

Maximum output power «DC 24


V out» 1.2 W @ 50 mA!

A separate isolating transformer  
must be used for higher  
performance!

## Connection on the MP-Bus




## Connection BACnet MS/TP / Modbus RTU




**Further electrical installations****Functions with specific parameters (configuration necessary)**


Connection BACnet MS/TP / Modbus RTU with analogue setpoint (hybrid mode)



Connection BACnet MS/TP / Modbus RTU with analogue primary/secondary operation

**Sensor connection**

Connection of active sensors (BACnet MS/TP / Modbus RTU)



Possible input voltage range:


0...10 V

Resolution 5 mV

To capture for example:

- Active temperature sensors
- Flow sensors
- Pressure / differential pressure sensors

Switching contact connection (BACnet MS/TP / Modbus RTU)



Switching contact requirements:

The switching contact must be able to switch a current of 16 mA at 24 V accurately.


To capture for example:

- Flow monitors
- Operation / malfunction messages of chillers

## Further electrical installations

## Sensor connection

Connection of passive sensors (BACnet MS/TP / Modbus RTU)




1)	2)
500 Ω...2 kΩ	+/-1%
2 kΩ...10 kΩ	+/-2%
10 kΩ...55 kΩ	+/-6%

- 1) Resistance range
- 2) Tolerance measured value

Compensation of the measured value is recommended

- Suitable for Ni1000 and Pt1000
- Suitable Belimo types 01DT-..

## Operating controls and indicators




## ⑤ Push-button and LED display green

Off: No power supply or malfunction  
 On: In operation  
 Press button: Triggers test run, followed by standard mode

## ⑥ Push-button and LED display yellow

Off: Standard mode  
 On: Test run active  
 Flickering: BACnet / Modbus communication active  
 Flashing: Request for addressing from MP client  
 Press button: Confirmation of the MP addressing



## Auxiliary switch settings

**⚠ Note:** Perform settings on the actuator only in deenergised state.

For the auxiliary switch position settings, carry out points ① to ④ successively.

## ① Gear train disengagement

Opening the manual override cover and adjusting the hand crank.  
 Manual override is possible.

## ② Manual override

Turn the hand crank until the desired switching position **A** is indicated and then remove the hand crank.


## ③ Auxiliary switch

For the auxiliary switch position settings, carry out points ① to ④ successively.

Opening the auxiliary switch adjustment cover and adjusting the hand crank.  
 Turn the hand crank until the arrow points to the vertical line.

## ④ Terminals

Connect continuity tester to S4 + S5 or to S4 + S6.  
 If the auxiliary switch should switch in the opposite direction, rotate the hand crank by 180°.



## Service

Using Belimo Assistant 2, device parameters can be modified. Belimo Assistant 2 can operate on a smartphone, tablet or PC. The available connection options vary depending on the hardware on which Belimo Assistant 2 is installed.

For more information about Belimo Assistant 2, refer to the Quick Guide – Belimo Assistant 2.



**Wireless connection**

Belimo devices marked with the NFC logo can be accessed either directly with an NFC-capable smartphone or with a Bluetooth-capable smartphone connected to Belimo Assistant Link.

Requirement:

- NFC- or Bluetooth-capable smartphone or tablet
- Belimo Assistant 2 (Google Play and Apple App Store)

Align the NFC-capable smartphone or Belimo Assistant Link with the device's NFC logo so that both NFC antennas are superposed.




## Service


## Wired connection

Belimo devices can be accessed by connecting Belimo Assistant Link to the USB port on a PC or laptop and to the service socket or MP-Bus wire on the device.

Belimo Assistant 2 acts as MP client. Therefore, no other MP client shall be connected to the device.



## Dimensions



## Further documentation

- Tool connections
- BACnet Interface description
- Modbus Interface description
- Overview MP Cooperation Partners
- Introduction to MP-Bus Technology
- MP Glossary
- The complete product range for water applications
- Data sheets for butterfly valves
- Installation instructions for actuators and/or butterfly valves
- General notes for project planning
- Quick Guide – Belimo Assistant 2