MP/2/BUS



Communicative RobustLine damper actuator for adjusting dampers in HVAC plants, comparable industrial plants and technical building installations

- Air damper size up to approx. 4 m²
- Torque motor 20 Nm
- Nominal voltage AC/DC 24 V
- Control modulating, communicative 2...10 V variable
- Position feedback 2...10 V variable
- Communication via Belimo MP-Bus
- Conversion of sensor signals
- Optimum protection against corrosion and chemical influences, UV radiation, damp and condensation



Picture may differ from product

Technical data

_				
-	ectr	ıcəl	A 21	ra
_	CLU	wai	ua	La

Nominal voltage	AC/DC 24 V
Nominal voltage frequency	50/60 Hz
Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V
Power consumption in operation	3.5 W
Power consumption in rest position	1.4 W
Power consumption for wire sizing	6 VA
Connection supply / control	Cable 1 m, 4x 0.75 mm² (halogen-free)
Parallel operation	Yes (note the performance data)
Communicative control	MP-Bus

Data bus communication

Functional data

Number of nodes	MP-Bus max. 8
Torque motor	20 Nm
Torque variable	25%, 50%, 75% reduced
Operating range Y	210 V
Input impedance	100 kΩ
Operating range Y variable	Start point 0.530 V End point 2.532 V
Operating modes optional	Open/close 3-point (AC only) Modulating (DC 032 V)
Position feedback U	210 V
Position feedback U note	Max. 0.5 mA
Position feedback U variable	Start point 0.58 V End point 2.510 V
Position accuracy	±5%
Direction of motion motor	selectable with switch 0/1
Direction of motion variable	electronically reversible
Direction of motion note	Y = 0 V: At switch position 0 (ccw rotation) / 1 (cw rotation)
Manual override	with push-button, can be locked
Angle of rotation	Max. 95°
Angle of rotation note	can be limited on both sides with adjustable mechanical end stops
Running time motor	150 s / 90°
Running time motor variable	86346 s
Sound power level, motor	45 dB(A)
Adaptation setting range	manual





Technical data			
	Functional data	Adaptation setting range variable	No action Adaptation when switched on Adaptation after pushing the manual override button
		Override control	MAX (maximum position) = 100% MIN (minimum position) = 0% ZS (intermediate position, AC only) = 50%
		Override control variable	MAX = (MIN + 32%)100% MIN = 0%(MAX – 32%) ZS = MINMAX
		Mechanical interface	Universal shaft clamp 1420 mm
		Position indication	Mechanical, pluggable
	Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
		Power source UL	Class 2 Supply
		Degree of protection IEC/EN	IP66/67
		Degree of protection NEMA/UL	NEMA 4X
		Housing	UL Enclosure Type 4X
		EMC	CE according to 2014/30/EU
		Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14
		UL Approval	cULus according to UL60730-1A, UL60730-2-14 and CAN/CSA E60730-1 The UL marking on the actuator depends on the production site, the device is UL-compliant in any case
		Type of action	Type 1
		Rated impulse voltage supply / control	0.8 kV
		Pollution degree	4
		Ambient humidity	Max. 100% RH
		Ambient temperature	-3050°C [-22122°F]
		Storage temperature	-4080°C [-40176°F]
		Servicing	maintenance-free

1.8 kg

Weight Weight



Safety notes



- This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.
- Junction boxes must at least correspond with housing IP degree of protection!
- The cover of the protective housing may be opened for adjustment and servicing. When it is closed afterwards, the housing must seal tight (see installation instructions).
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- The cables must not be removed from the device installed in the interior.
- To calculate the torque required, the specifications supplied by the damper manufacturers
 concerning the cross-section and the design, as well as the installation situation and the
 ventilation conditions must be observed.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.
- The information on chemical resistance refers to laboratory tests with raw materials and finished products and to trials in the field in the areas of application indicated.
- The materials used may be subjected to external influences (temperature, pressure, constructional fixture, effect of chemical substances, etc.), which cannot be simulated in laboratory tests or field trials.
- The information regarding areas of application and resistance can therefore only serve as a
 guideline. In case of doubt, we definitely recommend that you carry out a test. This
 information does not imply any legal entitlement. Belimo will not be held liable and will
 provide no warranty. The chemical or mechanical resistance of the materials used is not
 alone sufficient for judging the suitability of a product. Regulations pertaining to
 combustible liquids such as solvents etc. must be taken into account with special reference
 to explosion protection.
- Flexible metallic cable conduits or threaded cable conduits of equal value are to be used for UL (NEMA) Type 4X applications.
- When used under high UV loads, e.g. extreme sunlight, the use of flexible metallic or equivalent cable conduits is recommended.

Product features

Fields of application

The actuator is particularly suitable for utilisation in outdoor applications and is protected against the following weather conditions:

- Wood drying
- Animal breeding
- Food processing
- Agriculture
- Indoor swimming pools / bathhouses
- Rooftop ventilation plant rooms
- General outdoor applications
- Alternating climate
- Laboratories

Resistances

Noxious gas test EN 60068-2-60 (Fraunhofer Institut ICT / DE) Salt fog spray test EN 60068-2-52 (Fraunhofer Institut ICT / DE)

Ammoniac test DIN 50916-2 (Fraunhofer Institut ICT / DE) Climate test IEC60068-2-30 (Trikon Solutions AG / CH)

Disinfectant (animals) (Trikon Solutions AG / CH)

UV Test (Solar radiation at ground level) EN 60068-2-5, EN 60068-2-63 (Quinel / Zug CH)

Used materials

Actuator housing polypropylene (PP)

Cable glands / hollow shaft polyamide (PA)

Connecting cable FRNC

Clamp / screws in general Steel 1.4404

Seals EPDM

Form fit insert aluminium anodised



Product features

Operating mode

Conventional operation:

The actuator is connected with an analogue control signal Y (note the operating range) and drives to the position defined. The measuring voltage U serves for the electrical display of the actuator position 0...100% and as control signal for other actuators.

Operation on Bus:

The actuator receives its digital control signal from the higher level controller via the MP-Bus and drives to the position defined. Connection U serves as communication interface and does not supply an analogue measuring voltage.

Converter for sensors

Connection option for a sensor (passive or active sensor or switching contact). The MP actuator serves as an analogue/digital converter for the transmission of the sensor signal via MP-Bus to the higher level system.

Configurable device

The factory settings cover the most common applications. Single parameters can be modified with Belimo Assistant 2.

Simple direct mounting

Simple direct mounting on the damper shaft with a universal shaft clamp, supplied with an anti-rotation mechanism to prevent the actuator from rotating.

Manual override

Manual override with push-button possible (the gear train is disengaged for as long as the button is pressed or remains locked).

Adjustable angle of rotation

Adjustable angle of rotation with mechanical end stops. Standard setting 0...90°. The housing cover must be removed to set the angle of rotation.


High functional reliability

The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.

Home position

The first time the supply voltage is switched on, i.e. at the time of commissioning, the actuator carries out a synchronisation. The synchronisation is in the home position (0%).

The actuator then moves into the position defined by the control signal.



Adaptation and synchronisation

An adaptation can be triggered manually by pressing the "Adaptation" button or with Belimo Assistant 2. Both mechanical end stops are detected during the adaptation (entire setting range).

Automatic synchronisation after pressing the manual override button is configured. The synchronisation is in the home position (0%).

The actuator then moves into the position defined by the control signal.

A range of settings can be made using Belimo Assistant 2.

Accessories

Tools	Description	Туре
	Service tool for wired and wireless setup, on-site operation and troubleshooting.	Belimo Assistant 2
	Belimo Assistant Link Bluetooth and USB to NFC and MP-Bus converter for configurable and communicative devices	LINK.10
	Connecting cable 5 m, A: RJ11 6/4 LINK.10, B: 6-pin for connection to service socket	ZK1-GEN
	Connecting cable 5 m, A: RJ11 6/4 LINK.10, B: free wire end for connection to MP/PP terminal	ZK2-GEN
Electrical accessories	Description	Туре
	Auxiliary switch 2x SPDT add-on, grey	S2A GR
	Feedback potentiometer 140 Ω add-on	P140A
	Feedback potentiometer 1 kΩ add-on	P1000A
	Feedback potentiometer 10 k Ω add-on	P10000A
Gateways	Description	Туре
	Gateway MP to BACnet MS/TP	UK24BAC



Accessories

Description	Туре
Gateway MP to Modbus RTU	UK24MOD

Electrical installation




Supply from isolating transformer.

Parallel connection of other actuators possible. Observe the performance data.


Wire colours:

- 1 = black
- 2 = red
- 3 = white
- 5 = orange





AC/DC 24 V, modulating




1	2	3		
~L	⊸ L	2 V		
⊸~L	⊸~L	10 V	(O.

Further electrical installations


Functions with basic values (conventional mode)

Override control with AC 24 V with relay contacts



	1	2	а	b	С	
	→-L	⊸_L	~ <u></u>	- - -	- -	0 %
	→\L	⊸_L	⊸ _	⊸^L	⊸ _	ZS 50%
	⊸/L	⊸~L	⊸~L			100%
ı	→ L	⊸_L	- <u>-</u>	-J-	⊸~L	Υ

Override control with AC 24 V with rotary switch






Further electrical installations


Functions with basic values (conventional mode)

Control remotely 0...100% with positioner SG..


Minimum limit with positioner SG..



Primary/secondary operation (position-dependent)



Control with 4...20 mA via external resistor



Caution:


The operating range must be set to DC 2...10 V.
The 500 Ohm resistor converts the 4...20 mA current signal to a voltage signal DC 2...10 V.



Further electrical installations

Functions with basic values (conventional mode)

Functional check



Procedure


- 1. Connect 24 V to connections 1 and 2
- 2. Disconnect connection 3:
- With direction of rotation 0:

Actuator rotates to the left

- With direction of rotation 1:
- Actuator rotates to the right
- 3. Short-circuit connections 2 and 3:
- Actuator runs in opposite direction

MP-Bus

MP-Bus Network topology




There are no restrictions for the network topology (star, ring, tree or mixed forms are permitted).

Supply and communication in one and the same 3-wire cable


- no shielding or twisting necessary
- no terminating resistors required

Connection on the MP-Bus




Max. 8 MP-Bus nodes

Connection of active sensors



- Supply AC/DC 24 V
- Output signal 0...10 V (max. 0...32 V)
- Resolution 30 mV

Connection of external switching contact




- Switching current 16 mA @ 24 V
- Start point of the operating range must be configured on the MP actuator as ≥0.5 V



Further electrical installations

MP-Bus


Connection of passive sensors





- 1) Depending on the type
- 2) Resolution 1 Ohm Compensation of the measured value is recommended

Functions with specific parameters (configuration necessary)

Override control and limiting with AC 24 V with relay contacts









Control open/close

Override control and limiting with AC 24 V with rotary switch




Caution:

The "Close" function is only guaranteed if the start point of the operating range is defined as min. 0.5 V.




Control 3-point with AC 24 V





Operating controls and indicators



Direction-of-rotation switch

Switch over: Direction of rotation changes

2 Push-button and LED display green

Off: No power supply or malfunction

On: In operation

Press button: Triggers angle-of-rotation adaptation, followed by standard mode

3 Push-button and LED display yellow

Off: Standard mode

On: Adaptation or synchronisation process active

Flickering: MP-Bus communication active

Flashing: Request for addressing from MP client
Press button: Confirmation of the addressing

4 Manual override button

Press button: Gear train disengages, motor stops, manual override possible
Release Gear train engages, synchronisation starts, followed by standard


button: mode

5 Service plug

For connecting configuration and service tools

Check power supply connection

2 Off and 3 On Possible wiring error in power supply





Service


Using Belimo Assistant 2, device parameters can be modified. Belimo Assistant 2 can operate on a smartphone, tablet or PC. The available connection options vary depending on the hardware on which Belimo Assistant 2 is installed.

For more information about Belimo Assistant 2, refer to the Quick Guide – Belimo Assistant 2.




Wired connection

Belimo devices can be accessed by connecting Belimo Assistant Link to the USB port on a PC or laptop and to the Service Socket or MP-Bus wire on the device.




Dimensions


Shaft length



Clamping range

OĮ.		◇ I
1420	1014	1420







Further documentation

- Overview MP Cooperation Partners
- Tool connections
- Introduction to MP-Bus Technology
- Quick Guide Belimo Assistant 2

Application notes

• For digital control of actuators in VAV applications patent EP 3163399 must be considered.