

ZoneTight™, 2-way, Internal thread

- For closed cold and warm water systems
- For switching functions and 2-point controls on the water side of air-handling units and heating systems
- Snap-assembly of the actuator





Type overview			
ype			DN
2075Q-K			20
echnical data			
Functional data	nal data V	/alve size [mm]	0.75" [20]
	F	Fluid	chilled or hot water, up to 60% glycol
	- F	Fluid Temp Range (water)	36212°F [2100°C]
	Ē	Body Pressure Rating	360 psi
	(Close-off pressure ∆ps	75 psi
	Ī	Differential pressure ∆pmax	40 kPa
	F	low characteristic	equal percentage
	Ā	Angle of rotation note	Operating range 1590°
	Ī	Installation position	upright to horizontal (in relation to the stem)
	S	Servicing	maintenance-free
	F	Flow Pattern	2-way
	Ī	_eakage rate	0%
	(Controllable flow range	75°
	(Cv	9.8
N	Materials V	/alve body	forged brass
	S	Spindle	brass
	S	Spindle seal	EPDM O-ring
	S	Seat	PTFE, O-Ring EPDM
	S	Seat	PTFE
	- F	Pipe connection	NPT female ends
	-	O-ring	EPDM (lubricated)
	Ē	Ball	chrome plated brass
Suitable a	ctuators N	Non-Spring	CQB
	_		

Safety notes



Electrical fail-safe

WARNING: This product can expose you to lead which is known to the State of California to cause cancer and reproductive harm. For more information go to www.p65warnings.ca.gov
If temperature exceeds 212°F operating range due to a boiler control failure the valve will

CQKB(X)

safely contain the hot water but manufacturers product warranty becomes invalid. Valve and actuator replacement is at the expense of others.



Product features

Application

The QCV zone valves are suited for large commercial buildings where higher close-off and the ability to change flow is desired. Common applications include unit ventilators, fan coil units, VAV reheat coils, fin tube casing, radiant panels and duct coils. The valve fits in space restricted areas and can be assembled without the use of tools.

Product features

Mode of operation

The ball valve is adjusted by a rotary actuator. The rotary actuator is controlled by an on/off signal or by a commercially available modulating or floating point control system and moves the ball of the ball valve – the throttling device – to the position preset by the control signal. Open the ball valve is carried out counterclockwise and close it clockwise.

Simple direct mounting

Tool-free snap assembly.


The actuator can be plugged on the valve by hand (Caution! Just vertical movements). Pins must match the holes on the flange.

The mounting orientation in relation to the valve can be selected in 180° increments. (Possible two times)

Installation notes

Recommended installation positions

The ball valve can be installed upright to horizontal. The ball valve may not be installed in a hanging position, i.e. with the spindle pointing downwards.



Water quality requirements

Belimo valves are regulating devices. For the valves to function correctly in the long term, they must be kept free from particle debris (e.g. welding beads during installation work). The installation of a suitable strainer is recommended.

Servicing


Ball valves and rotary actuators are maintenance-free.

Before any service work on the final controlling device is carried out, it is essential to isolate the rotary actuator from the power supply (by unplugging the electrical cable if necessary). Any pumps in the part of the piping system concerned must also be switched off and the appropriate slide valves closed (allow all components to cool down first if necessary and always reduce the system pressure to ambient pressure level).

The system must not be returned to service until the ball valve and the rotary actuator have been correctly reassembled in accordance with the instructions and the pipeline has been refilled by professionally trained personnel.

Flow direction

Direction of flow in both directions possible.





Flow setting

The angle of rotation of the actuator can be changed by a clip in 2.5° increments. This is used to set the kvs value (maximum flow rate of the valve).

Remove end stop clip and place at desired position.

After every change of the flow setting by means of end stop clip, an adaptation must be triggered on the modulating actuators.

Dimensions

Туре	DN	Weight
Z2075Q-K	20	0.44 lb [0.20 kg]

