

# Differential pressure sensor Air

Differential pressure transmitter with 8 selectable ranges and outputs 0...5 V, 0...10 V or 4...20 mA. For monitoring the differential pressure of air and other non-flammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fans V-belts as well as the use in pressure differential systems. Options available with LCD display, auto-zero feature. IP65 / NEMA 4X rated housing.





Type Overview						
Туре	Measuring range [Pa]	Output signal active pressure	Burst pressure	Display type	Additional features	
22ADP-184	-1002500	05 V, 010 V, 420 mA	40 kPa	-	-	
22ADP-184A	-1002500	05 V, 010 V, 420 mA	40 kPa	-	Auto-Zero	
22ADP-184B	-1002500	05 V, 010 V, 420 mA	40 kPa	LCD	Auto-Zero	
22ADP-184L	-1002500	05 V, 010 V, 420 mA	40 kPa	LCD	-	
Technical data						
	Electrical data	Nominal voltage		AC/DC 24 V		
		Nominal voltage range		AC 1929 V / DC 1535 V		
		Power consumption		4.3 VA		
		Power consumption	DC	2.3 W		
		Electrical connection	١	Pluggable spring loa 2.5 mm²	ded terminal block max	
		Cable entry		Cable gland with stra	ain relief ø68 mm	
	Functional data	a Medium		Air		
		Multirange		8 measuring ranges	selectable	
		Voltage output		1 x 05 V, 010 V, n	nin. resistance 10 kΩ	
		Current output		1x 420 mA, max. resistance 500 $\Omega$		
		Output signal active note		Output 05/10 V selectable with switch		
		Display	Display		LCD, 29x35 mm	
				with backlight		
					, inch WC (configurable	
		Typical response tim	ne	Adjustable 0.8 s or 4	.U S	
	<b>Measuring data</b> Measured values			Differential pressure Volumetric flow (with		
		Measuring fluid		Air and non-aggress	<u> </u>	
	Specification Pressure	Sensing element tec	hnology	Piezo measuring ele	ment	
•						



# **Technical data**

Specification Pressure	Measuring range pressure settings	Setting Range [Pa] Range [inch WC] Factor settin
		S0 02500 010
		S1 02000 08
		S2 01500 06
		S3 01000 04
		S4 0500 02
		S5 0250 01 S6 0100 00.4
		56 0100 00.4 S7 -100100 -0.40.4
	Accuracy	
	Accuracy	Deviation compared to the reference device measuring range ≤500 Pa: ±5 Pa
		measuring range \$500 Pa: ±10 Pa
	Long term stability	±2.5% FSO (Full Scale Output) / 4 yr.
	Long term stability	12.5% 150 (run scale output) / 4 yr.
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
	Power source UL	Class 2 Supply
	Degree of protection IEC/EN	IP65
	Degree of protection NEMA/UL	NEMA 4X
	Housing	UL Enclosure Type 4X
	EU Conformity	CE Marking
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-6
	Quality Standard	ISO 9001
	UL Approval	cULus acc. to UL60730-1A/-2-6, CAN/CSA E60730-1
	Type of action	Type 1
	Rated impulse voltage supply	0.8 kV
	Pollution degree	3
	Ambient humidity	Max. 95% RH, non-condensing
	Ambient temperature	-1050°C [14122°F]
	Fluid temperature	-1050°C [15120°F]
Materials	Housing	Cover: PC, orange
	-	Bottom: PC, orange
		Seal: NBR70, black
		UV resistant
	Cable gland	PA6, black

# Safety notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.



#### Remarks

## Automated zero-point calibration (Auto Zero)

Transmitters equipped with the auto-zero calibration are maintenance-free.

The auto-zero calibration electronically adjusts the transmitter zero every 10 minutes. The function eliminates all output signal drift due to thermal, electronic or mechanical effects. The auto-zero adjustment takes approx. 4 seconds after which the device returns to its normal measuring mode. During the 4 second adjustment period, the output and display values will freeze to the latest measured value.

## Manual zero-point calibration

After initial commissioning

To carry out the zero-point calibration, the device must be connected to the power supply at least 15 minutes beforehand.

Calibration interval

≤250 Pa 3 months

≤500 Pa 6 months

>500 Pa 12 months

#### Procedure

• Release both tube connectors from the pressure ports + and -


(Carry out the manual zero-point calibration even if the display shows 0.)

- Press the button "Manual zero-point calibration" until the LED lights permanently
- Wait until the LED flashes again and reinstall the tube connectors to the pressure ports (pay attention to + and -)

# **Indicators and Operation**

#### **Indicators**

Depending on the device and the number of measured values, the display automatically scales. Parameters, such as the fading in/out of measured values, brightness and traffic light function, are changed via the app or bus system. During the boot process, the software and hardware versions are displayed.



- Fault / sensor failure
- 2 Service / visual inspection due
- 3 TLF (traffic light function) active (thresholds for display colour changes)
- Radio active (not available)
- Status bar
- 6 Measured value (\* appears when TLF function is activated for this value)
- 7 Unit of measure
- 8 Measured value

# Parts included

Description	Туре
Mounting plate L housing	A-22D-A10
Duct connector kit, Plastic, PVC tube 2 m, 2x duct connector (plastic) for 22ADP	A-22AP-A08
Dowels	
Screws	



## **Accessories**

Optional accessories	Description	Туре		
	Duct connector, Metal, L 40 mm, Tube connection 5 mm	A-22AP-A02 A-22AP-A04		
	Duct connector, Metal, L 100 mm, Tube connection 5 mm			
	Connection adapter flex conduit, M20x1.5, for cable gland 1x 6 mm, Multipack 10 pcs.	A-22G-A01.1		
Tools	Description	Туре		
	Belimo Duct Sensor Assistant App	Belimo Duct		
		Sensor Assistant		
		Арр		
	Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05		
	* Bluetooth dongle A-22G-A05			
	Certified and available in North America, European Union, EFTA States and UK.			

## Service

#### **Tools connection**

This sensor can be operated and configured using the Belimo Duct Sensor Assistant App.

When using the Belimo Duct Sensor Assistant App, the bluetooth dongle is required to enable communication between the app and the Belimo sensor.


For standard operation and configuration of the sensor, the bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above.

### Requirement:

- Bluetooth dongle (Belimo Part No: A-22G-A05)
- Bluetooth-capable smartphone
- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)

# Procedure:

- Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB  $\,$
- Connect Bluetooth-capable smartphone with Bluetooth dongle
- Select configuration in the Belimo Duct Sensor Assistant App




# Wiring diagram



When switching from 0...10 V to 0...5 V output voltage also the current will be adjusted from 4...20 mA to 4...12 mA.


# Wiring diagram



# Wiring note power supply AC


For the sensor to function properly, polarity must be observed with a DC supply as well as an AC supply.


If the AC supply is connected incorrectly, i.e. if the wires are reversed, this can lead to the destruction of the sensor.





# **Dimensions**





Туре	Weight
22ADP-184	0.38 kg
22ADP-184A	0.38 kg
22ADP-184B	0.41 kg
22ADP-184L	0.40 kg

# **Further documentation**

• Installation instructions