

# Duct sensor CO<sub>2</sub> / Temperature

Active sensor (4...20 mA / 0...10 V) for measuring  $CO_2$  or with integrated temperature sensor. See options below for integrated sensors. Dual channel  $CO_2$  technology. IP65 / NEMA 4X rated housing.





Туре	Output signal active CO <sub>2</sub>	Output signal active temperature
22DTC-13	420 mA, 05 V, 010 V	420 mA, 05 V, 010 V
22DC-13	420 mA, 05 V, 010 V	-
Technical data		
Electrical data	Nominal voltage	AC/DC 24 V
	Nominal voltage range	AC 1929 V / DC 1535 V
	Power consumption AC	4.3 VA
	Power consumption DC	2.3 W
	Electrical connection	Pluggable spring loaded terminal block max. 2.5 mm²
	Cable entry	Cable gland with strain relief ø68 mm
Functional data	Medium	Air
	Voltage output	1 x 05 V, 010 V, min. resistance 10 kΩ (Typo 22DC-13)
		$2$ x 05 V, 010 V, min. resistance 10 k $\Omega$ (Typo 22DTC-13)
	Current output	1x 420 mA, max. resistance 500 $\Omega$ (22DC-13) 2x 420 mA, max. resistance 500 $\Omega$ (22DTC-13)
	Output signal active note	Output 05/10 V with Jumper adjustable
Measuring data	Measured values	CO₂ Temperature
Specification CO₂	Sensing element technology	Non-dispersive infrared (NDIR) dual channel
	Measuring range	Default setting: 02000 ppm With A-22G-A05: 05000 ppm
	Accuracy	±(50 ppm + 3% of measured value)
	Long term stability	±50 ppm p.a.
	Calibration	Self-calibration Dual channel
	Time constant $\tau$ (63%) in the air duct	Typical 33 s @ 1 m/s
Specification temperature active	Measuring range	050°C [32122°F]
	-	
·	Accuracy temperature	±0.3°C @ 25°C [±0.5°F @ 77°F]
	Accuracy temperature  Long term stability	±0.3°C @ 25°C [±0.5°F @ 77°F] ±0.04°C p.a. @ 21°C [±0.07°F p.a. @ 70°F]



#### **Technical data**

#### Safety data

Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
Power source UL	Class 2 Supply
Degree of protection IEC/EN	IP65
Degree of protection NEMA/UL	NEMA 4X
Housing	UL Enclosure Type 4X
EU Conformity	CE Marking
Certification IEC/EN	IEC/EN 60730-1
Quality Standard	ISO 9001
UL Approval	cULus acc. to UL60730-1A/-2-9, CAN/CSA E60730-1/-2-9
Type of action	Type 1
Rated impulse voltage supply	0.8 kV
Pollution degree	3
Ambient humidity	Max. 95% RH, non-condensing
Ambient temperature	050°C [32122°F]
Fluid humidity	Max. 95% RH, non-condensing
Fluid temperature	050°C [32122°F]
Operating condition airflow	min. 0.3 m/s max. 12 m/s
Housing	Cover: PC, orange Bottom: PC, orange Seal: NBR70, black UV resistant
Cable gland	PA6, black
Probe material	PA6, black

### Safety notes



Materials

This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

# **Product Features**

#### CO2 dual channel technology

All  $CO_2$  sensors are subject to drift, which is caused by the ageing process of the components and requires regular calibration and adjustment or replacement of the sensors. The dual-channel technology minimises this drift by compensating for the majority of the ageing effects of the measuring channel through adjustment with a reference channel.

This makes it possible to use dual-channel sensors in applications with 24/7 occupancy. Regular calibration with fresh outdoor air, as is the case with sensors with ABC logic, is not necessary with dual-channel sensors. It is recommended to recalibrate the sensor after 5 years of operation.



#### Remarks

#### General remarks concerning sensors

Sensing devices with a transducer should always be operated in the middle of the measuring range to avoid deviations at the measuring end points. The ambient temperature of transducer electronics should be kept constant. The transducers must be operated at a constant supply voltage (±0.2 V). When switching the supply voltage on/off, onsite power surges must be avoided.

Remark: Occurring draft leads to a better carrying-off of dissipative power at the sensor. Thus temporally limited fluctuations might occur upon temperature measurement.

# Build-up of self-heating by electrical dissipative power

Temperature sensors with electronic components always have a dissipative power which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. The dissipative power should be taken into account when measuring temperature.

In case of a fixed operating voltage (±0.2 V), this is normally done by adding or reducing a constant offset value. As Belimo transducers work with a variable operating voltage, for reasons of production engineering only one operating voltage can be taken into consideration. Transducers 0...10 V / 4...20 mA have a standard setting at an operating voltage of DC 24 V. This means that at this voltage, the expected measuring error of the output signal will be the least. For other operating voltages, the offset error will be increased by a changing power loss of the sensor electronics.

If a readjustment directly at the active sensor should be necessary during later operation, this can be done with the following adjustment methods.

- For sensors with NFC or dongle with the corresponding Belimo app
- For sensors with a trimming potentiometer on the sensor board
- For bus sensors via bus interface with a corresponding software variable

## Requirements to be met by the medium

To ensure the ongoing and optimal functioning of the sensor, it is imperative that the air being measured is free of dust or other contaminants that could accumulate on the sensor element.

#### Parts included

Description	Туре	
Mounting flange for duct sensor 19.5 mm, up to max. 120°C [248°F],	A-22D-A35	
Plastic		

Optional accessories	Description	Туре
	Replacement filter sensor probe tip, wire mesh, Stainless steel	A-22D-A06
	Connection adapter flex conduit, M20x1.5, for cable gland 1x 6 mm, Multipack 10 pcs.	A-22G-A01.1
	Mounting plate L housing	A-22D-A10
Tools	Description	Туре
	Belimo Duct Sensor Assistant App	Belimo Duct
		Sensor Assistan
		Арр
	Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05

Certified and available in North America, European Union, EFTA States and UK.



# Service

#### **Tools connection**

This sensor can be operated and configured using the Belimo Duct Sensor Assistant App.

When using the Belimo Duct Sensor Assistant App, the bluetooth dongle is required to enable communication between the app and the Belimo sensor.


For standard operation and configuration of the sensor, the bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above.

# Requirement:

- Bluetooth dongle (Belimo Part No: A-22G-A05)
- Bluetooth-capable smartphone
- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)


#### Procedure:

- Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB
- Connect Bluetooth-capable smartphone with Bluetooth dongle
- Select configuration in the Belimo Duct Sensor Assistant App





# Wiring diagram




① Status LED Slow blinking (0.5 Hz): Ok Fast blinking (4 Hz): Failure

# Wiring note power supply AC


For the sensor to function properly, polarity must be observed with a DC supply as well as an AC supply.


If the AC supply is connected incorrectly, i.e. if the wires are reversed, this can lead to the destruction of the sensor.





# **Dimensions**





Туре	Probe length	Weight
22DTC-13	180 mm	0.28 kg
22DC-13	150 mm	0.26 kg

# **Further documentation**

• Installation instructions