

Duct sensor Humidity / Temperature

For measuring the relative or absolute humidity and temperature in duct applications. Instead of the humidity signal, the enthalpy or the dewpoint can be selected as an output signal. With BACnet MS/TP communication and integrated 0...10 V outputs. IP65 / NEMA 4X rated housing.





Type Co	mmunication	Output signal active to	emperature	Output signal active humidity	
22DTH-16M B.	Cnet MS/TP	net MS/TP 05 V, 010 V		05 V, 010 V	
Technical data					
Electrical d	ta Nominal voltage	2	AC/DC 24	4 V	
	Nominal voltage	e range	AC 192	9 V / DC 1535 V	
	Power consump	tion AC	4.3 VA		
	Power consump	tion DC	2.3 W		
	Electrical conne	ction	Pluggabl 2.5 mm²	le spring loaded terminal block max.	
	Cable entry		Cable gla	and with strain relief 2x ø6 mm	
Data bus communicati	on Communication	Communication		BACnet MS/TP	
	Number of node	es	BACnet s	see interface description	
Functional d	ta Medium		Air		
	Voltage output	Voltage output		$2x05$ V, 010 V, min. resistance 10 $k\Omega$	
	Output signal ac	ctive note	Output 0)5/10 V with Jumper adjustable	
Measuring d	ta Measured value	S		es	
Specification temperature act	ve Sensing elemen	t technology		-based capacitive sensor with stainle e mesh filter	
	Measuring rang	e	-2080° (default s Attention listed do tempera	ole via BACnet C [-5175°F] setting) n: The maximum measuring range es not indicate the allowable fluid ture for the sensor. Refer to safety the maximum fluid temperature	
	Accuracy tempe	rature		25°C [±0.5°F @ 77°F]	
	Long term stabi			p.a. @ 21°C [±0.09°F p.a. @ 70°F]	
	Time constant τ	(63%) in the air duct	Typical 1	25 s @ 3 m/s	



Technical data

Specification Humidity	Sensing element technology	Polymer-based capacitive sensor with stainless steel wire mesh filter
	Measuring range	Adjustable via BACnet
		Default setting: 0100% RH
	Measuring range absolute humidity	Adjustable via BACnet
		Default setting: 080 g/m³
	Measuring range enthalpy	Adjustable via BACnet
		Default setting: 085 kJ/kg
	Measuring range dew point	Adjustable via BACnet

Measuring range dew point	Adjustable via BACnet		
	Default setting: -2080°C [-5175°F]		
Accuracy	±2% between 080% RH @ 25°C		
Long term stability	±0.3% RH p.a. @ 21°C @ 50% RH		
Time constant τ (63%) in the air duct	Typical 10 s @ 3 m/s		

Safety data

Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
Power source UL	Class 2 Supply
Degree of protection IEC/EN	IP65
Degree of protection NEMA/UL	NEMA 4X
EU Conformity	CE Marking
Certification IEC/EN	IEC/EN 60730-1
Quality Standard	ISO 9001
UL Approval	cULus acc. to UL60730-1A/-2-9/-2-13, CAN/CSA E60730-1/-2-9
Type of action	Type 1
Rated impulse voltage supply	0.8 kV
Pollution degree	3
Ambient humidity	Max. 95% RH, non-condensing
Ambient temperature	-3550°C [-30120°F]
Fluid humidity	Short-term condensation permitted
Fluid temperature	-4080°C [-40175°F]
Operating condition airflow	max. 12 m/s
Housing	Cover: PC, orange

Safety notes



Materials

Cable gland

This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Bottom: PC, orange Seal: NBR70, black UV resistant PA6, black

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.



Remarks

General remarks concerning sensors

Sensing devices with a transducer should always be operated in the middle of the measuring range to avoid deviations at the measuring end points. The ambient temperature of transducer electronics should be kept constant. The transducers must be operated at a constant supply voltage (± 0.2 V). When switching the supply voltage on/off, onsite power surges must be avoided.

Remark: Occurring draft leads to a better carrying-off of dissipative power at the sensor. Thus temporally limited fluctuations might occur upon temperature measurement.

Build-up of self-heating by electrical dissipative power

Temperature sensors with electronic components always have a dissipative power which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. The dissipative power should be taken into account when measuring temperature.

In case of a fixed operating voltage (± 0.2 V), this is normally done by adding or reducing a constant offset value. As Belimo transducers work with a variable operating voltage, for reasons of production engineering only one operating voltage can be taken into consideration. Transducers 0...10 V / 4...20 mA have a standard setting at an operating voltage of DC 24 V. This means that at this voltage, the expected measuring error of the output signal will be the least. For other operating voltages, the offset error will be increased by a changing power loss of the sensor electronics.

If a readjustment directly at the active sensor should be necessary during later operation, this can be done with the following adjustment methods.

- For sensors with NFC or dongle with the corresponding Belimo app
- For sensors with a trimming potentiometer on the sensor board
- For bus sensors via bus interface with a corresponding software variable

Application notice for humidity sensors

The humidity sensor is extremely sensitive. Touching the sensor element or exposing it to aggressive substances like chlorine, ozone, ammonia, hydrogen peroxide or ethanol (i.e. as a cleaning agent) may affect the measurement accuracy.

Long term operation outside the recommended conditions (5...60°C and 20...80% RH) can result in a temporary offset. After returning into the recommended range, this effect disappears.

Parts included

Description	Туре
Mounting flange for duct sensor 19.5 mm, up to max. 120°C [248°F],	A-22D-A35
Cable Gland with strain relief #6 8 mm	

Accessories

Optional accessories	Description	Туре	
	Replacement filter sensor probe tip, wire mesh, Stainless steel	A-22D-A06	
	Connection adapter flex conduit, M20x1.5, for cable gland 1x 6 mm, Multipack 10 pcs.	A-22G-A01.1	
	Connection adapter flex conduit, M20, for cable gland 2x 6 mm, Multipack 10 pcs.	A-22G-A02.1	
	Mounting plate L housing	A-22D-A10	
Tools	Description	Туре	
	Belimo Duct Sensor Assistant App	Belimo Duct	
		Sensor Assistant	
		Арр	
	Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05	



Accessories

* Bluetooth dongle A-22G-A05

Certified and available in North America, European Union, EFTA States and UK.

Service

Tools connection

This sensor can be operated and configured using the Belimo Duct Sensor Assistant App.

When using the Belimo Duct Sensor Assistant App, the bluetooth dongle is required to enable communication between the app and the Belimo sensor.


For standard operation and configuration of the sensor, the bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above.

Requirement:

- Bluetooth dongle (Belimo Part No: A-22G-A05)
- Bluetooth-capable smartphone
- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)

Procedure:

- Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB
- Connect Bluetooth-capable smartphone with Bluetooth dongle
- Select configuration in the Belimo Duct Sensor Assistant App



Wiring diagram




Supply from isolating transformer.

The wiring of the line for BACnet (MS/TP) has to be carried out in accordance with applicable RS-485 regulations.

Modbus / BACnet: Supply and communication are not galvanically isolated. Connect earth signal of the devices with one another.

Wiring diagram




① and ③: Status LED Slow blinking (0.5 Hz): Ok Fast blinking (4 Hz): Failure

- ② Red: Error
- ③ Yellow: Tx
- 4 Yellow: Rx

Detailed documentation


The separate document, BACnet PICS, informs about the PICS, MAC addressing and bus termination (DIP1 & DIP2).


Wiring RS-485 BACnet MS/TP






Dimensions







Туре	Probe length	Weight
22DTH-16M	140 mm	0.26 kg

Further documentation

- BACnet Interface description
- Installation instructions