

Room sensor CO₂ / Humidity / Temperature

For measuring the temperature, humidity and CO_2 in the room. The room units can be seamlessly connected to existing third-party controllers. With MP-Bus communication and integrated 0...10 V output. The device is configured via NFC using Belimo Assistant 2.









Type Overview					
Туре	Communication	Output signal active CO ₂	Output signal active humidity	Output signal active temperature	
22RTM-19-1	MP-Bus	05 V, 010 V, 210 V	05 V, 010 V, 210 V	05 V, 010 V, 210 V	
22RTH-19-1	MP-Bus	-	05 V, 010 V, 210 V	05 V, 010 V, 210 V	
22RT-19-1	MP-Bus	-	-	05 V, 010 V, 210 V	
Technical data					
	Electrical data	Nominal voltage	AC/DC 24 V		
		Nominal voltage range	AC 19.228.8 V /	AC 19.228.8 V / DC 19.228.8 V	
		Power consumption AC	1 VA	1 VA	
		Power consumption DC	0.5 W		
		Electrical connection	<u> </u>	minal 0.251.5 mm ²	
		Electrical connection note		er conductors only nd Canada: CL2 or higher	
		Cable entry	Back side Top side Bottom side		
	Data bus communication	Communication MP-Bus			
		Number of nodes	MP-Bus max. 8 (1	6)	
	Functional data	Medium	Air		
		Voltage output	kΩ (Type 22RT-19		
			2 x 05 V, 010 \ kΩ (Type 22RTH-1	/, 210 V, min. resistance 5 9-1)	
				/, 210 V, min. resistance 5	
		Output signal active note	Output 05 V, 0 V selectable via N	.10 V (factory setting), 210 FC	
		Display	light function). Th	sed for the CO ₂ TLF (traffic se LED can be configured and elimo Assistant 2. (Type	

(P-)22RTM-..).



Technical data

Measuring data	Measured values	CO ₂ Relative humidity Dew point Temperature
Specification CO₂	Sensing element technology	Non-dispersive infrared (NDIR) dual channel
	Measuring range	Default setting: 02000 ppm
	Accuracy	±(50 ppm + 2% of measured value)
	Long term stability	±20 ppm p.a.
Specification temperature active	Measuring range	050°C [32122°F] (default setting)
	Accuracy temperature	±0.3°C @ 25°C [±0.5°F @ 77°F]
	Long term stability	±0.03°C p.a. @ 25°C [±0.05°F p.a. @ 77°F]
Specification Humidity	Measuring range	Default setting: 0100% RH
	Measuring range dew point	Default setting: -5050°C [-60120°F]
	Accuracy	±2% between 090% RH @ 25°C
	Long term stability	±0.25% RH p.a. @ 25°C @ 50% RH
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
	Power source UL	Class 2 Supply
	Degree of protection IEC/EN	IP30
	EU Conformity	CE Marking
	Quality Standard	ISO 9001
	UL Approval	cULus according to UL60730-1, CAN/CSA E60730-1
	Type of action	Type 1
	Rated impulse voltage supply	0.5 kV
	Pollution degree	2
	Ambient humidity	Max. 95% RH, non-condensing
	Ambient temperature	050°C [32122°F]
	Storage temperature	-4070°C [-40160°F]
Materials	Housing	PC, white, RAL 9003 UL94V-0

Safety notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.



Product Features

CO2 dual channel technology

All CO_2 sensors are subject to drift, which is caused by the ageing process of the components and requires regular calibration and adjustment or replacement of the sensors. The dual-channel technology minimises this drift by compensating for the majority of the ageing effects of the measuring channel through adjustment with a reference channel.

This makes it possible to use dual-channel sensors in applications with 24/7 occupancy. Regular calibration with fresh outdoor air, as is the case with sensors with ABC logic, is not necessary with dual-channel sensors. It is recommended to recalibrate the sensor after 5 years of operation.

Remarks

General remarks concerning sensors

The measuring result is influenced by the thermal characteristics of the wall. A solid concrete wall responds to thermal fluctuations within a room more slowly than a light-weight structure wall. A room sensor always detects a mixture of air and wall temperature. This means that the radiant heat of the wall, which is important for comfort, is also included in the measurement result.

Remark: Occurring draft leads to a better carrying-off of dissipative power at the sensor. Thus temporally limited fluctuations might occur upon temperature measurement.

Build-up of self-heating by electrical dissipative power

Temperature sensors with electronic components always have a dissipative power which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. The dissipative power should be taken into account when measuring temperature.


Belimo room sensors have adaptive temperature compensation for the entire supply voltage range. This ensures that the ambient temperature is detected with the highest accuracy at all times.

Application notice for humidity sensors

The humidity sensor is extremely sensitive. Touching the sensor element or exposing it to aggressive substances like chlorine, ozone, ammonia, hydrogen peroxide or ethanol (i.e. as a cleaning agent) may affect the measurement accuracy.

Long term operation outside the recommended conditions (5...50°C and 20...80% RH) can result in a temporary offset. After returning into the recommended range, this effect disappears.

Indicators and Operation





CO₂ TLF (traffic light function), available on the (P-)22RTM-.. sensor

Colours: green, yellow and red. LED can be configured and deactivated via Belimo Assistant 2.

Parts included

Screws

Accessories

Tools	Description	Туре
	Service tool for wired and wireless setup, on-site operation and	Belimo Assistant 2
	troubleshooting.	



Accessories

DescriptionTypeBelimo Assistant Link Bluetooth and USB to NFC and MP-Bus converter
for configurable and communicative devicesLINK.10

Service


NFC connection

Belimo devices marked with the NFC logo can be operated with Belimo Assistant 2. Requirement:

- NFC- or Bluetooth-capable smartphone
- Belimo Assistant 2 (Google Play and Apple AppStore)

Align NFC-capable smartphone on the device so that both NFC antennas are superposed.

Connect Bluetooth-enabled smartphone via the Bluetooth-to-NFC converter ZIP-BT-NFC to the device. Technical data and operating instructions are shown in the ZIP-BT-NFC data sheet.



Wiring diagram



Analogue outputs: The analogue outputs AO1, AO2 and AO3 can be configured via NFC.


Factory settings:

AO1: Temperature

AO2: Humidity


AO3: CO₂

Wiring diagram





Dimensions



Type	Weight
22RTM-19-1	0.16 kg
22RTH-19-1	0.090 kg
22RT-19-1	0.090 kg

Further documentation

- Overview MP Cooperation Partners
- Description Data-Pool Values
- Installation instructions
- Quick Guide Belimo Assistant 2