BELIMO

Technical data sheet P-22RT..-1800D-1

Room sensor / Room operating unit CO_2 / Humidity / Temperature

For measuring temperature, humidity and CO_2 in the room and for controlling the room temperature and/or ventilation. The high-contrast ePaper touch display ensures best readability and intuitive operation. Thanks to MP-Bus communication and integrated analogue outputs, the room operating units can be seamlessly connected to existing third-party controllers. Commissioning and configuration of the device is conveniently done with Belimo Assistant 2. The ePaper display can be optimised for a wide range of applications.

5 YEAR WARRANTY

MP-BUS

NFC

Type Overview

Type	Communication	I/O	Measured values	Setpoint	Display type
P-22RTM-1800D-1	MP-Bus	3x AO	CO_2, Temperature, Relative humidity, Dew point	Temperature, Volumetric flow	ePaper touch display and LED
P-22RTH-1800D-1	MP-Bus	3x AO	Temperature, Relative humidity, Dew point	Temperature, Volumetric flow	ePaper touch display
P-22RT-1800D-1	MP-Bus	3x AO	Temperature	Temperature, Volumetric flow	ePaper touch display

Technical data

Electrical data	Nominal voltage	AC/DC 24 V
	Nominal voltage range	AC 19.2...28.8 V / DC 19.2...28.8 V
	Power consumption AC	max. 1 VA (V output) max. 4 VA (mA output)
	Power consumption DC	max. 0.5 W (V output) max. 2 W (mA output)
	Electrical connection	Spring loaded terminal 0.25...1.5 mm^2
	Electrical connection note	Cable type USA and Canada: CL2 or higher
	Cable entry	Back side Top side Bottom side
Data bus communication	Communication	MP-Bus
	Number of nodes	MP-Bus max. 8 (16)
Functional data	Medium	Air
	Display	ePaper touch display and LED, 69x62 mm The LED is used for the CO_2 TLF (traffic light function). The LED can be configured and deactivated via Belimo Assistant 2. (Type (P-)22RTM-..).
	Input/Output	3x analogue output: 0...10 V (factory setting), 0...5 V, 2...10 V or 4...20 mA, selectable with Belimo Assistant 2
	Input/Output Note	V output: min. resistance 5 kΩ mA output: max. resistance 500 Ω

Technical data

Measuring data	Measured values	CO_2 Relative humidity Dew point Temperature
Specification CO_2	Sensing element technology	Non-dispersive infrared (NDIR) dual channel
	Measuring range	Default setting: 0...2000 ppm
	Accuracy	±(50 ppm + 2% of measured value)
	Long term stability	±20 ppm p.a.
Specification temperature active	Measuring range	0...50°C [32...122°F] (default setting)
	Accuracy temperature	±0.3°C @ 25°C [±0.5°F @ 77°F]
	Long term stability	±0.03°C p.a. @ 25°C [±0.05°F p.a. @ 77°F]
Specification Humidity	Measuring range	Default setting: 0...100% RH
	Measuring range dew point	Default setting: -50...50°C [-60...120°F]
	Accuracy	±2% between 0...90% RH @ 25°C
	Long term stability	±0.25% RH p.a. @ 25°C @ 50% RH
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
	Power source UL	Class 2 Supply
	Degree of protection IEC/EN	IP30
	EU Conformity	CE Marking
	Quality Standard	ISO 9001
	Type of action	Type 1
	Rated impulse voltage supply	0.5 kV
	Pollution degree	2
	Ambient humidity	Max. 95% RH, non-condensing
	Ambient temperature	0...50°C [32...122°F]
	Storage temperature	-40...70°C [-40...160°F]
Materials	Housing	PC, white, RAL 9003 UL94V-0

Safety notes

This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Product Features

California title 24

The room units (P-)22RTM-18..-1 meet the requirements outlined in California Title 24, Part 6 for demand-controlled ventilation systems. Features such as the ability to record the highest CO_2 levels over the past 30 days are accessible via Belimo Assistant 2.

Product Features

Dynamic temperature compensation

Active temperature sensors with electronic components always have a thermal dissipation that influences the temperature measurement. The dissipative heat correlates with the level of the applied supply voltage and the levels of the analogue outputs.

Belimo room temperature sensors have adaptive temperature compensation, which reliably compensates for the device's self-heating for all permissible supply voltages and output levels. This ensures that the room temperature is recorded with maximum accuracy at all times.

CO_2 dual channel technology

All CO_2 sensors are subject to drift, which is caused by the ageing process of the components and requires regular calibration and adjustment or replacement of the sensors. The dual-channel technology minimises this drift by compensating for the majority of the ageing effects of the measuring channel through adjustment with a reference channel.

This makes it possible to use dual-channel sensors in applications with 24/7 occupancy. Regular calibration with fresh outdoor air, as is the case with sensors with ABC logic, is not necessary with dual-channel sensors. It is recommended to recalibrate the sensor after 5 years of operation.

Remarks

General remarks concerning sensors

The measuring result is influenced by the thermal characteristics of the wall. A solid concrete wall responds to thermal fluctuations within a room more slowly than a light-weight structure wall. A room sensor always detects a mixture of air and wall temperature. This means that the radiant heat of the wall, which is important for comfort, is also included in the measurement result.

Remark: Occurring draft leads to a better carrying-off of dissipative power at the sensor. Thus temporally limited fluctuations might occur upon temperature measurement.

Application notice for humidity sensors

The humidity sensor is extremely sensitive. Touching the sensor element or exposing it to aggressive substances like chlorine, ozone, ammonia, hydrogen peroxide or ethanol (i.e. as a cleaning agent) may affect the measurement accuracy.

Long term operation outside the recommended conditions (5...50°C and 20...80% RH) can result in a temporary offset. After returning into the recommended range, this effect disappears.

Indicators

Indicators

The operating display is an ePaper display that reflects light like normal paper. It is therefore a non-illuminated display with an integrated touch control panel.

The representation on the display can be designed freely, depending on the requirements. Function blocks can be switched on or off by using Belimo Assistant 2. By default, all actual values and temperature setpoint adjustments are visible on the display.

Indicators



1. **Current CO_2 concentration: 0...2000 ppm**
2. **CO_2 TLF (traffic light function), available on the (P-)22RTM-.. sensor**

   Colours: green, yellow and red. LED can be configured and deactivated via Belimo Assistant 2.
3. **Current temperature: 0...50°C or -32...122°F**
4. **Current relative humidity: 0...99%**
5. **Fan speed display: 6 levels**
6. **Eco mode: Symbol is displayed if this mode is activated**
7. **Cooling mode: Information provided by controller via bus**
8. **Heating mode: Information provided by controller via bus**
9. **Warning / Error**

   Symbol is displayed if an internal error occurred or if warning is transmitted by the controller via the connected bus (external error).
10. **External input, information provided by controller via bus**
11. **HVAC system status**

    Symbol is displayed if the HVAC system is either completely off or in building protection mode. If this symbol is activated, the rest of the display is blank.

Operation

Operation The operating elements on the ePaper display are touch fields that can be operated with the finger. The touch fields are only active if the corresponding element is also displayed.



1. **Temperature setpoint: Set the desired temperature**

Absolute setpoint:	10...40.0°C or 50...104.0°F
Relative setpoint:	-5...5°C / °F

   Adjustable and restrictable via Belimo Assistant 2
2. **Fan speed display: 6 levels**
3. **Eco mode: Symbol is displayed if this mode is activated**
4. **Fan speed setpoint: Set the desired fan level**
5. **Max mode: Symbol is displayed if this mode is activated**
6. **HVAC system status**

   Symbol can be displayed if the HVAC system is either completely off or in building protection mode. If this symbol is activated, the rest of the display is blank.

Parts included

Screws

Accessories

Tools	Description	Type
	Service tool for wired and wireless setup, on-site operation and troubleshooting.	Belimo Assistant 2

Accessories

Description	Type
Belimo Assistant Link Bluetooth and USB to NFC and MP-Bus converter for configurable and communicative devices	LINK.10

Service

NFC connection

Belimo devices marked with the NFC logo can be operated with Belimo Assistant 2.

Requirement:

- NFC- or Bluetooth-capable smartphone
- Belimo Assistant 2 (Google Play and Apple AppStore)

Align NFC-capable smartphone on the device so that both NFC antennas are superposed.

Connect Bluetooth-enabled smartphone via the Bluetooth-to-NFC converter ZIP-BT-NFC to the device. Technical data and operating instructions are shown in the ZIP-BT-NFC data sheet.



Wiring diagram

Analogue outputs: The analogue outputs AO1, AO2 and AO3 can be configured via NFC.

Factory settings:

AO1: Temperature

AO2: Setpoint Temperature

AO3: 22RTH-..: Humidity, 22RTM-..: CO_2, 22RT-..: Off

Wiring diagram



Dimensions





Further documentation

- Overview MP Cooperation Partners
- Description Data-Pool Values
- Installation instructions
- Quick Guide – Belimo Assistant 2